

Installation Instructions: Magura

Tools Needed

- T25 Torx Wrench
- Hammer
- Small Punch

Step 1

Using T25, remove brake lever body from handlebars



Step 2

If your model is equipped with BAT adjuster remove that first, if you don't have this skip to step 5

Step 3

To remove the BAT adjuster - on the bottom side of the lever, push in the clip and turn 90. Take care not to loose the spring as it releases.



Step 4

Remove the label carefully and set aside to re-install later.



Step 5

Place the brake body onto a flat surface with a hole to allow the pin to press out the far side and using hammer and punch remove the pin



Step 6

Remove stock lever
Slide brake line boot down to make install easier



Step 7

Install included spring into Ti-Pro lever with hook aligned as shown



Step 8

Place lever into brake body and re-install pin using hammer and punch to set it slightly sub-flush



Step 9

Reinstall decal and BAT adjust if previously removed

Work lever back and forth to ensure no binding

Step 10

Reinstall on bars, reinstall brake boot and set reach

