

Installation Instructions: TRP Evo Series Brakes

Tools Needed

- 4mm allen wrench
- 2mm allen wrench
- 1.5mm allen wrench
- Small flat head screwdriver
- Pin punch
- Small hammer

Step 1

Using 4mm, loosen brake lever, rotate on bars to access pin



Step 2

Using 2mm Allen wrench, loosen rear set screw 2-3 turns



Step 3

Dial in (clockwise) adjustment knob as far as possible. Loosen 1.5mm set screw and remove knob



Step 4

Using pin punch and hammer drive out pin



Step 5

Use flat head screw driver to turn in adjustment screw all the way until lever is free - remove lever from brake body



Step 6

Remove threaded barrel from old lever and place into new lever



Step 7

Place new lever into brake body and using flat head turn adjuster screw CCW to engage



Take care not to lose stock flanged bushing

Step 8

Tighten adjust screw until pin hole is aligned, then drive pin back through new lever



Step 9

Install adjustment knob by lining up set screw with flat on shaft, then tightening set screw



Step 10

Pull lever forward to reach rear set screw and tighten with 2mm wrench



Step 11

Rotate lever back to normal position and set reach



Disclaimer: Hexagon Components is not liable for damage to bike due to improper installation, if in doubt please take your bike to a qualified bike shop technician